



MAGNETIC STRIPE READERS

USER MANUAL

MSRv008 Bluetooth




English version



USER MANUAL

MSRv008 BLUETOOTH



Terms and conditions	3
Warranty	4
Parts identification	5
MSRv008 installation	7
CRFSuite software installation	9
Software usage	12
MSRv008 signal codes	29
Charging the battery	29
Connections	30
About us	31

Terms and Conditions - General

This is a legal agreement between you, the user, and CardReaderFactory (we, our, us). This agreement covers all hardware and software that is distributed with our products, for which there is no separate license agreement.

By opening or breaking the seal of the package, using our products, installing or downloading the software, or using our products and/or the software that has been preloaded or is embedded in our products, you agree to be bound by the terms of this agreement.

TO THE MAXIMUM EXTENT PERMITTED BY THE APPLICABLE LAW, UNDER NO CIRCUMSTANCES SHALL CARDREADERFACTORY OR ANY OF ITS LICENSORS BE RESPONSIBLE FOR ANY DATA TRANSFERRED TO AND FROM OUR PRODUCTS, FOR ITS USAGE, FOR ANY LOSS OF DATA OR INCOME OR ANY SPECIAL, INCIDENTAL, CONSEQUENTIAL OR INDIRECT DAMAGES HOWSOEVER CAUSED.

You must understand that you, and not us, is responsible for all data transferred to and from our products and for their usage. We are not responsible for anything you do with our products. You must not use our products in any way that will, or is likely to breach any law. You must not use our products for any fraudulent purposes, or in connection with a criminal offence or other unlawful activity.

You must not use our products to obtain any information without the owner's knowledge or approval. You must not send, use or reuse any material that is illegal, offensive, abusive, indecent, defamatory, obscene or menacing; or in breach of copyright, trademark, confidence, privacy or any other right; or is otherwise injurious to third parties; or objectionable; or which consists of or contains software viruses, political campaigning, commercial solicitation, chain letters, mass mailings or any "spam". You and your applications of our products must not cause annoyance, inconvenience or needless anxiety. You will safeguard the use and distribution of our products and make any effort to prevent illegal use from occurring.

This license is effective until terminated. It will terminate upon the conditions set forth above or if you fail to comply with any of its terms. Upon termination, you agree that the Hardware, Software and accompanying materials, and all copies thereof, will be destroyed. This agreement is governed by the laws of United Kingdom, People's Republic of China, Hong Kong and British Virgin Islands.

Each provision of this agreement is severable. If a provision is found to be unenforceable, this finding does not affect the enforceability of the remaining provisions, terms, or conditions of this agreement.

This agreement is binding on successors and assigns.

You agree and we agree to waive, to the maximum extent permitted by law, any right to a jury trial with respect to any dispute and all disputes will be resolved through binding arbitration. Because this waiver may not be effective in some jurisdictions, this waiver may not apply to you. You acknowledge that you have read this agreement, that you understand it, that you agree to be bound by its terms, and that this is the complete and exclusive statement of the agreement between you and us regarding the Hardware and Software.

Terms and Conditions - Warranty

We warrant that all of our products are free from defects in material and workmanship under normal use and service for a period of sixty (60) days for OEM products and one (1) year for all other products unless otherwise stated. This period is counted from the date of the shipment. Our option, any device returned for warranty work and found to be defective by us.

To repair the device under warranty, the customer has to complete this form first: <http://www.cardreaderfactory.com/shop/repairs.html>. We will then e-mail an RMA number, the shipping address and instructions. The product will then have to be returned by the customer to the specified address (to our factory or facility). We will, without charge, repair or replace at our option, any product returned for warranty work and found to be defective by us.

If we will find that the returned product is defective and falls within the terms of this warranty, we will ship free of charge the product, back to the customer with a postal or courier service at our own discretion. We will also credit to the customer's account with us, the amount he/she paid for shipping, but not exceeding 50USD. This credit can only be used for paying other orders with us and has no other cash value.

This warranty will not apply to any of our products which should have been:

- Repaired or altered (except by us)
- Tampered with or the seal case has been broken (if applicable)
- Poured onto glue or any other kind of liquids / substances
- Subjected to misuse, negligence, or accident.

In no case shall our liability exceed the purchase price. The mentioned provisions do not extend the original warranty period of any product which either been repaired or replaced by us. The user is solely responsible for determining if the product is usable in his or her application.

We will not cover, under any circumstances, any customs or customs processing charges. Any such charges will be billed to the customer.

If a product has been returned for warranty repair and it is found to be in working order, we will charge a revision fee (usually 80 USD unless otherwise stated) and the shipping fees to return it back to the customer; in this case we will not cover the customer's shipping fees.

Our details

CardReaderFactory is a trading name. For company information details, please read:

<http://www.cardreaderfactory.com/shop/terms-and-conditions.html>

<http://www.cardreaderfactory.com/shop/about-us.html>

PARTS IDENTIFICATION

MSRv008



.....
Your portable Bluetooth magnetic
stripe reader.
.....

Plastic rail



.....
This plastic rail has a 3 track low profile
read head which can be used to read up
to 1,000,000 cards.
.....

Rechargeable battery



.....
3.7 Volt, 40mA, Li-Ion rechargeable
battery.
.....

USB charging cable



This cable charges the battery until it is fully charged. It will automatically stop when required. It does not work on a timer therefore will not damage your battery.

To use it, plug one part of the cable into any USB port from your computer and the other part into the MSRv008 reader.

During the charging a led on the cable will turn on to indicate that it is charging the battery and will turn off when the battery is fully charged.



The LED on the cable will blink if there is any problem when charging.

This cable is used to charge the battery of the MSRv008 devices using any USB port. This cable cannot be used to connect to the reader using CRFSuite; **It only charges the battery.**



BLUETOOTH is a trademark owned by
Bluetooth SIG, Inc., U.S.A.

MSRv008 Installation

The device can be accessed, configured and data can be downloaded wireless via Bluetooth. The range of the Bluetooth module of your MSRv008 is up to 100 meters. In order for the communication to be possible you need a computer with Bluetooth capabilities or a Bluetooth dongle attached to your computer if it does not have Bluetooth embedded hardware.

1. Connect with battery

1.1 Connect your battery with MSRv008 device

1.2 Turn on the micro switch on the PCB. You will see the a green light blinking which means it has been turned on.

2. Open Bluetooth

2.1 Make sure your receiver is within the range of your Bluetooth reader.

The data access for MSRv008 Bluetooth is up to 100 meters. Your Bluetooth receiver has to have 100 meters range in order to get the information from your reader. If the range of your receiver is smaller than 100 meters you will have to adjust the distance accordingly

2.2 Setup

Open Control Panel on your Computer.




Image 1: Add a device

From the “Hardware and Sound” tab, click on the section named “Add a device”. It will pop out a new window, showing devices that need installation.




Image 2: Add device MSRv008

If you can see an icon like the one you see above in Image 2 your MSRv008 reader can be synchronized with your computer. Click to select the MSRv008 Build “xxxxxx” icon. Then, click Next to get a window like the one in Image 3. Here you are asked to input the pairing code for the MSRv008. The default pairing code is “0000”. Input the code “0000” and click Next. Next window should tell that your device is ready to use.

If you cannot see an icon like the one in Image 2, please make sure that both your MSRv008 and the Bluetooth on your computer are turned on.



Image 3: Enter pairing code

CRFSuite Installation

1. Install the drivers and software

The software for MSRvXXX has been designed and tested on Windows XP and Windows 7 (32 and 64bit). We do not guarantee or support its usage on any other operating system.

Insert the CD into your CD-Rom.



NOTE: On each Windows computer the CD-ROM has attributed a letter. In this manual we will use as example **E:** as the CD-ROM drive letter.

It might vary on each computer. You can find out the letter of your CDROM by clicking on "My Computer" icon.

A window with our "Terms and conditions" should automatically pop out. If your computer does not show this window, double click on **E:** (your CD-ROM drive). Read our "Terms and conditions" carefully. After accepting our "Terms and conditions", the interface will guide you through the installation process, offering drivers, user manuals for all our products and useful video tutorials about how to use and samples.

Here we present you the steps:

Step 1 - Terms and conditions

By using our software and hardware you agree to be bound by our "Terms and conditions" which you can read at the beginning of this manual. Please make sure that you have read and agreed with them. You can also read them by inserting the CD into your CD-ROM drive. If you do not agree, please return the reader with all its accessories to us for a full refund.




Image 4: Terms and conditions

Step 2 (optional) - Windows setup

a) Some documents might require your computer to be able to display PDF files. If your computer is not able to display them, please install Foxit Reader from our cd. You can install it by clicking the **Install Fox Reader** button.

b) If you are running Windows XP and Vista, you might need to **install** .NET 2.0 framework. If it isn't already installed, CRFSuiteSetup will try to download it from the internet. You can skip the download by installing the .NET framework from our CD. Please click on **Install .NET Framework** and chose the version for your PC (32 bit or 64 bit).

.NET Framework 2.0 SP2 for x86 machines (for 32 bits system installation)

.NET Framework 2.0 SP2 for x64 machines (for 64 bits system installation)

If the installation fails, you will need to cleanup your computer of the failed .NET 2.0 Framework using the software downloaded by clicking the button clean-up. Only after your computer has been cleaned, you can attempt to reinstall the .NET Framework.

Step 3 - Drivers installation



You have to install the driver for USB cable in order to access your reader. Select your device from our user friendly interface. It will guide you through the installation process. You need to do this only once on any computer you use. Without a successful install of the drivers, the software will not detect your reader. Please **click** the button **Install driver for USB data cable** from the menu (Image 6), to successfully install the driver.




Image 5: Chose your device

Step 4 - Install the MSR software (CRFSuite)

CRFSuite is the software that accesses, configures, downloads and decodes the data from your reader. Please click the button **Install CRFSuite** from the CD's User interface.

If the installer needs to download the .NET 2.0 Framework and you do not have an internet connection, please refer to Step 2 of this manual.

If CRFSuite does not start and shows the message "The application failed to initialize properly (0xc0000135)." it means that **you have not installed .NET 2.0 Framework** and you need to repeat Step 2.

To watch a demonstration of CRFSuite, please view our video tutorial on **How to use** , by selecting it from your Cd's menu, or refer to this manual.

If for some reason you cannot use the CD-ROM drive (eg. you don't have a CD drive on your computer) you can **download** the software from this web address:

<http://www.cardreaderfactory.com/download.html>




Image 6: Install your software

Software usage

2. Using the software

The software used to download, edit and view the data read with the MSRv008 is called CRFSuite.

2.1 Step 1 - Connect to the MSRv008




Image 7: CRFSuite startup




Image 8: Connect and Log In

CRFSuite is designed to work with all our card readers therefore it has more options than MSRv008 needs. Please open CRFSuite. You should see a window as the one in Image 7. As your reader is connected through Bluetooth, please select the Bluetooth radio button.

After selecting the Bluetooth radio button, CRFSuite will detect your MSRv008. It will be displayed in the combo box below the radio buttons.

There should be two entries in the list. Select the first entry. If you can not find any entry, press Rescan and check again. After selecting the first entry in combo box, press "Connect" and you will receive the message "Connected; authentication required".

At this point, CRFSuite has connected to the MSRv008 and will ask for a password. The default one is "1234". You will be able to change it later. Type in the password and press Log In (Image 8). If you've logged in successfully, a window will pop up asking if you want to change the default password.

2.2 Device Info box




Image 9: Device Info box

On the upper area of the window there is the "Device Info" box. In here you can see the status of your device. The information displayed includes the date and time of the device, the number of swipes in memory, the number of swipes in device's life time and the memory used/available.

You can also read more information from each field by holding your mouse pointer over this field for a few seconds.

The State field should be always "OK". If it isn't, there's a fault with your device. CRFSuite will display instead of OK a short description of the fault. To refresh the data from this box, clicking anywhere inside it.

2.2.1 Commands




Image 10: Commands box

Download - downloads the data from the device.

You will be prompted to choose the name of the file. All the files downloaded from the MSRv008 are in .CRF format which is encrypted.

Erase - erases the content of the device. During the erase, the device's led will blink from time to time which indicates that it is erasing the memory.



Warning: Once this button is pressed, the data will be permanently erased and there will be no way to recover it from your device.

Decode - opens the decode window which allows you to see, modify, print and save the downloaded data. If you have not downloaded anything from MSRv008 it will ask for the file that you want to decode. We will discuss this window into next chapter.

Reboot - will reinitialize your device as if the power was cut. Normally you will not use this feature. Please note that this feature is disabled for demo devices.

Log Out - It logs you out from the device. If you do not log out, the next time you (or someone else) who connects to the device will not be asked for authentication. For this reason, we strongly recommend that you log out or close CRFSuite before disconnecting the device from the computer.

Upgrade - This button is only displayed for demo versions and enables full functionality of your device. In order to upgrade your device you need to purchase from us an upgrade password. This password you will have to paste (CTRL-V) or type in the password boxes displayed after clicking on Upgrade" button. Once the upgrading is done, this button will disappear and the name of the device will change from "Demo Card Reader" into "Card Reader". Please do not try random passwords as you will block the device and you will be unable to use the device at all for a limited period of time. All blocked devices will display at any connection attempt a warning windows letting the user know for how long the device will remain in this state.




Image 11: Upgrade

Upgrade and change key: After log in , a window will pop up, showing that your device is a "Demo Card Reader" (Image 11). To upgrade your demo device to full functionality, you need to purchase the upgrade key from us. You can purchase it from this link:

<http://www.cardreaderfactory.com/shop/upgrade-codes.html>

Once you received the upgrade password, you can proceed upgrading by clicking the Upgrade button at the bottom of the window (Image 11).

Type in or paste the upgrade (key) password received via e-mail, in the text bar and click OK and then Yes to finish the upgrading.

At this point, you can see from the CRFSuite window that the Name of your device is changed to Card Reader and the Upgrade button is no longer present and message "Upgrading succeeded" will be seen at the bottom of the window.




Image 12: Key button

Clock - When you power on the device, it starts from 00:00:00 1/1/1970 GMT. You can synchronize the device date and time with your local time zone by pressing this button. You will be prompted with a text box like in Image 13.




Image 13 Change Clock




Image 14: Change password

- **Sync** - will synchronise the device clock with the computer's clock. All the values in the additional fields are ignored.
- **Ok** - will synchronise the clock with the values specified in the fields above.
- **Cancel** - the clock on the device will be left unchanged and you will be returned to the Step 2.

Password - This option changes the password for your device (Image 14). This is the one that you are asked in step 1.



Warning: If you forget the new password you will not be able to access the device any more and we won't be able to help you.

- **Ok** - will change the password with the one requested.
- **Cancel** - will not change the password and you will be returned to Step 2.
- **Show pass** - will show the password you entered for you to view.

2.2.2 Menus and its features

On the Menu Bar of the CRFSuite window, there are three menus: File, Device and Help.

File - it will get you a drop down list (Image 15) with following Sub Menus:




Image 15: File menu

Open... - will let you choose and open .txt and .crf files.

Device Manager - You can use Device Manager to view a list with present hardware devices on your computer and set properties for each device.

Install CRFSuite to flash drive... - You can browse and select a folder or a removable drive where you want CRFSuite to be installed. This feature will not install CRFSuite on your computer. You will have to run the program by clicking on the .exe file from the folder where you choose to install CRFSuite with this option.

Preferences - Will pop up the Preferences window. This allows you to configure the behaviour of CRFSuite.

Exit - Closes CRFSuite and any .crf files open.




Image 16: Preferences

The Preferences pop window has 3 tabs: Settings, Keys and OEM - which are explained below.

• **Settings** – (image 13) – allows you to associate CRFSuite software with .crf file format. Once associated you can double




Image 17: Edit keys

click on any file with .crf extension and CRFSuite will automatically open the file for you. Here you can also enable or disable the pop up dialogs which ask you:

- if you want to change the "1234" login password;
- if you want to open the file immediately after the download;

Keys – (Image 17) - You can edit stored encryption keys by ticking the check box of “Edit keys”. Your key will be stored here after you tick the check box of Remember Key in pop up window labeled “Enter Key” when you decode data or open a .crf file (this is also discussed in Decode the data part). Now you can edit or erase your keys in the text box. Click **Apply** to save your changes. Click **Cancel** to discard changes and exit the preferences. Click **OK** to confirm changes and exit.




Image 18: Change OEM feature

OEM – (Image 18) - If you point your mouse over the check box and label “Remove OEM features” a warning message will pop up. Please read it carefully before you decide to remove the OEM features. Ticking check box labeled “Remove OEM features” will allow you to rename the CRFSuite with a new title of your choice. Click **Apply** to save the changes. Click **OK** to save changes and exit. Click **Cancel** to discard changes and exit.




Image 19: Device menu

Device – will get a drop down list with Sub Menus as shown in Image 19.

Refresh info – Click this Sub Menu to refresh the info in Device Info box. You can also refresh the Device Info box by clicking anywhere inside the Main Window. If none of the parameters change it is because the information about your reader is unchanged; however with each refresh the device clock parameter should be updated.

New mode and Old mode

Since build number 6xxx, our MSR device have 2 read modes:

- The old mode was used in all readers with build numbers below 6000
- The new mode is the default read mode in all readers with the build number above 6xxx.

Difference between the two modes:

- The new mode can read 704 bits while the old mode was able to read 608 bits. As both specifications are above the magnetic cards standard, the advantage is noticeable only if you are using a customized card format.
- The new mode allows us to check if there is something wrong with the head.



NOTE: If your device works correctly in the new mode, it will also work perfectly in the old mode. In order to switch from one read mode to another, you just need to click on New mode or Old mode.

Firmware update – You can check your firmware version in the Device Info box. By clicking Firmware update (from file), you will be asked to select an .aes file extension format. If you click Firmware update (from internet) the software will connect to our server using an Internet connection and update your firmware automatically.

Help – This menu and its Sub Menus (Image 17) allows you to access help files and tutorials, report a bug, check for CRFSuite updates and check your current software version by clicking About..




Image 20: Help menu




Image 21: Build number

2.3 Obtain your decryption key

The data downloaded from your MSRv008 is encrypted with a military grade encryption (Rijndael-128). In order to decrypt the file, you need to have a key which is unique for each reader.

We never ship the key together with the reader. You need to confirm us that you have received the reader and we will send you the key. In order to obtain the key, you need to write an email to **support@cardreaderfactory.com** and ask us for the key.

You need to include into your email the build number of your device. This number is displayed in the Device Info box (please observe the red rectangle from Image 21). We will only send the key to the email that has been used to place the order so we can make sure that nobody else can obtain your own private key from us.

Please take good care of your key.



We will never disclose your key to anybody else (unless the law requires us to). To protect your privacy please change your key!




Image 22: Change key

Along with the upgrade key we emailed to you, there is also the master password in 4 numbers we provided.

This is the second password besides the default. Press the Key button, you will get a window as Image 22. Then, you can change your key in the Change key box by entering your new key in the Enter key text bar and enter the new key again in the Verify key text bar.

Click OK button to save your change and exit the Change key session.

Change key session.

Click Cancel to discard your change and exit the

If the new key is invalid, a popped-out window will ask you if you would like to generate a random key.

If you agree and press Yes in the dialog window, then the CRFSuite will fill in the text boxes with the new randomly generated key and will also write it into clipboard. At this point you can open any text editor application (notepad, word etc.) and press CTRL-V to paste the new key.

2.4 View and edit the data




Image 23: Enter key

If you have just downloaded a file from the reader, once you press the Decode button you will be presented with the window from Image 23.

To decode the file, you just need to paste (or type) our private key into the text box and press Accept.

If you want to skip this dialog for all future files encrypted with this key, you can ask CRFSuite to remember your key by clicking "Remember Key". Your key will be stored in File/Preferences/Keys and you can view, edit or erase it there. Enter Key window will only appear when open a .crf file that is encoded with an unknown key.



Note: Please note that there might be a security risk if someone else can get access to your computer.

There is also a check box of CBC in the Change key area. Note the CBC check box. It tells the reader that it can use the CBC (cipher block chaining) encryption mode which is stronger than the old encryption mode. If you choose to use this mode you will only be able to read the data with CRFSuite 3.1 or higher.

2.4.1 Open a .CRF file

In the upper menu, select File and then Open.... A new window will open which will allow you to select the ".crf" file that you want to decode. After you've selected the file, you will be asked for the decrypt key (the same window shown in the previous paragraph). All the files downloaded from the MSRv008 (.crf) are encrypted. The contents of these files cannot be accessed without a key therefore you will be asked for one each time you want to open these files. The key is 32 characters long and contains only numbers and letters from a to f. The software does not make any difference between upper case (e.g 'A') and lower case (e.g 'a').

2.4.2 View the data

If the key is OK, the program will decrypt the data and display it in the text box in the window as Image 24 shows. From now on, you can edit the file and arrange the data as you see fit. As you can see from the window, the text box is generally divided into two sections. The upper half area shows the most reliable decrypted data according to the settings and decoding of our Decode program. If you click or go to any cell of any Track column, you will see in the lower half area of the window all the variants of that decrypted data as well as the swipe direction and reliable rate relates to it. You can review all the variants and choose the one that you think most fit by clicking or going to that cell of variant. This will change the data in the Track field. To save the changes you made, click File, then click **Save or Save as..**




Image 24: Decode data

2.4.3 Saving the data

CRFSuite can save CRF, Text files and CSV files.

A text file is the human readable information and is NOT encrypted.

The data shown into the text file is the best guessed variant by our software. All other variants are not saved therefore they are lost.

A CSV file is "comma separated values" which can be imported by spreadsheet software such as Excel or Open Office. A CRF file is generated by CRFSuite which contains the decrypted data of the cards. A CRF file can only be opened by CRFSuite software.




Image 25: File menu in Decode window

To save after you edited and arranged the 'CRF' file, select File and then Save to the file you opened, or Save as... to a new named 'CRF' file as Image 25 shows.

You can also save the data in the file you opened and edited in other types of files as text document .txt and csv. (shown in spreadsheet program) by selecting File and then Export as .txt or .csv, like Image 25 shows.

Warning: Do not use the text files as 'CRF' replacement!

The text files do not contain important informations (variants, encoding, colors etc.). If you still need this information please make sure that you also save the document in CRF format.




Image 26: Warning for text files

Above warning information will also appear in a dialog window when you successfully exported your data into text files as shown in Image 26. And you can see the detailed explanation of the warning by clicking the 'Show details' icon on the pop-out Export text file window.

2.4.4 Edit the data




Image 27: Edit menu in Decode window

You can use the Edit menu in the upper Decode program window (Image 27) to edit and arrange your data by clicking the Edit and the items on the menu.

Undo – Reverses the last command or the last entry you input.

Redo – Reverses the action of the last Undo command.

Cut - Removes and copies the selection to the clipboard.

Copy - Copies the selection to the clipboard.

Paste - Inserts the contents of the clipboard at the location of the cursor, and replaces any selected text.

Delete - Removes the selection.




Image 28: Find function

Find... - Searches and highlights the data you want in the file. Input the data that you want to search in the text bar and click the Find Next button (Image 28), then the data you want to search will be highlighted in the file. Click the Find Next button, then the next occurrence will be highlighted.

You can keep pressing the Find Next button until the search has reached to the end of document.

You will be informed by a dialog window when you have reached the end. If the data you want to search does not exist in the document, a window will appear to warn you.

You can set the Find direction as Up or Down by clicking either of them.

To match case when searching, click the Match case box. Click Cancel to exit Find command and setting.

Find next - click this item on the Edit menu after you set your Find..., then the data you want can be highlighted and shown in the window. The shortcut for this function is F3 key as you can see in the menu.

Select All - click this item on the Edit menu, all the data in your document will be selected. Selecting data is useful to perform actions like cut/copy/paste/delete which are also available from the Edit menu.

EditMode - This menu has a submenu which includes 3 modes: "Edit on Enter", "Edit on F2" and "Text Edit". These options will change the behaviour of the editor and you should choose the behaviour that you find it easier to work with.

"Edit on Enter" – in order to edit a cell you will need to press Enter. You will be able to navigate the cells with the arrow keys from your keyboard.

"Edit on F2" - in order to edit a cell you will need to press F2. You will be able to navigate the cells with the arrow keys from your keyboard.

"Text Edit" - this will make the editor disregard the cells and behave like a normal text editor. You will be able to navigate with a cursor through all the characters.

2.4.4.1 View setting and toolbar

Click View in the upper window, you can go to the View menu as shown in Image 29. This menu contains commands for controlling the on-screen display of the document.

•**Fields Toolbar** - Shows or hides the field toolbars including Direction, Time, Track1, Track2, Track3, Settings and Resize Columns.

•**Direction** - shows or hides the Direction information in the document.

•**Time** - shows or hides the Time information in the document.

•**Track1** - shows or hides the Track1 information in the document.

•**Track2** - shows or hides the Track2 information in the document.

•**Track3** - shows or hides the Track3 information in the document.

•**Settings** - shows a window for you to do the format setting for your file.

•**Resize Columns** - goes back to the original column size of your file.




Image 29: View menu in Decode window

•**Quick Settings Toolbar** - Shows or hides the quick settings toolbar including DecodeMethod and Format.

•**Decode Method** - click on the text toolbar, choose any command to display the decoded data. Options are 'Show everything (including the errors)', 'Show only the valid data,hide the error' and Show the best guess'.

•**Format** - shows the format of the decoded data in the file. Put mouse pointer on each of the two text toolbars for detailed explanation.

•**Decode Toolbar** - Shows or hides the decoding settings including Grouping interval, Align and Filter.

•**Grouping interval** - cards with a time difference smaller than the number shown in this box will be colored in the file.

•**Align** - number in the box is the number of minimum common chars to align cards.

•**Filter** - input in the text toolbar the data you want to search, then entries contain in the text will be shown.

2.4.4.2 Tools

Image 30 shows the Tools menu in the window. There are three functions on this menu as below.

Delete empty card - this command key enables you to remove empty card data from you file. A small window will appear when you click this item on the menu. The popped-out window asks you to input a number to perform your command. Cards with all tracks with a number of characters equal or less than the number you input will be considered as empty. After input the number, the window will show you the numbers of cards found. Click Accept, found cards will be deleted. Click Cancel, you will exit from this command.




Image 30: Tools menu in Decode window

Show key - click this item, a window will show you your current key information for decoding. Meanwhile, your key information has been copied on the clipboard.

Settings - This feature allows you to preset your decode setting. Click the Tools menu, then Settings, there will appear a new window of Decode setting as Image 30 shows. You can also click the Settings button in the Fields Toolbar on the upper left of the window to go to the setting window (see the red rectangle in Image 30 for the Settings button). On the Decode Settings, there are below features.

Decoder - you can choose either Advanced or Simple mode. Advanced mode recommended as it is in grid mode which has more features. Simple mode is test mode.

•**Display settings** - you can set the data display here by choosing from the option menu in this area.

You can set the grouping interval by minutes, seconds or milliseconds. In the “Align by” text bar, you can input a number which is the number of minimum common chars to align cards. The swipe direction can be shown or hidden in the file if you click the check box of Show Direction. You can also click Show time to show or hide the time information in the file. Time can be shown in date/month/year/hour/minute/second or other mode according to the option you chose by clicking submenu bar besides the “Show time”.

•**Decoding parameters** - you can set the decode method by choosing from the options listed here. The Decode method includes three options as “Show everything (including the errors)”, “Show only the valid data, hide the errors” and “Show the best guess”. You can choose one mode you see fit. We recommend you to choose “Show the best guess” and the next feature “Use smart decoding”. Click in the box before Track1 will enable the window to shows or hides that track. Same with Track 2 and Track 3. The data shown in each track is decided by the standard you choose at the bottom of this area.

You can choose from 'ISO 7811 (IATA + ABA + THRIFT)' to 'Custom format'. For the BPC and Start information for each track, please refer back to Format on Quick Settings Toolbar.

•Click the box at the bottom to show or not show this window when opening a file.

•Click OK to save your settings and exit. Click Cancel to discard your last settings and exit.




Image 31: Decode setting

2.4.4.3 Shortcut and function keys for Decode program

Ctrl+O : open a .crf file

Ctrl+S: save a .crf file

Ctrl+Z: undo

Ctrl+Y: redo

Ctrl+X: cut

Ctrl+C: copy

Ctrl+V: paste

Del: delete

Ctrl+F: find query

F3 : find next

Ctrl+A: select all

Ctrl+E: resize columns

MSRv008 Signal codes

MSRv008 shows light signals as a feedback for the user.

Please find below the list with the meanings for these signals:

Normal operation:

Start Up - Blue LED (only) blinks twice rapidly (2x 25ms)

Read Card OK - Blue LED blinks once for 25 ms

Erasing Memory - Red LED turns on and off for an average of 1.5seconds intervals

Errors:

Card Read but not stored - Blue LED signals 5 times for 25ms; this signal is shown only by the demo version.

Other failures - on start up the Red LED will blink few times (not as normal). The error will be displayed by CRFSuite through a warning message as you log in. It will also be shown into the Status field.

Charging the battery

The reader is shipped with a rechargeable Li-Ion battery. When the battery runs out, it needs to be charged. We ship our card reader with a USB charging cable which you can connect to any powered USB port. The USB connector of charging cable is plugged into a powered USB port and the Micro USB connector of the charging cable it will be plugged into your MSRvXXX with the battery connected to it.

The cable charges the battery until it is fully charged and automatically stops. Charging time it is not controlled by timer therefore the charger will not damage your battery.

Note:

- While charging, the MSRv008 cannot be used to read any cards.
- This cable cannot be used to connect to the reader using CRFSuite. You can also use any other 3.7V Li-Ion charger to charge the battery.

Do not charge your battery at more than 4.2volts because it will blow up or catch fire. The red wire is plus (+) and the black wire is minus (-)

Connections

The MSRv008 is static sensitive therefore you need to handle it in a static free environment. This means that you need to wear at least an antistatic bracelet when you touch the electronics. If you do not wear static protection gear you risk damaging the electrostatic circuit.

The reader requires at least 2.8Volts to work correctly and a maximum of 3.8volts. Please read the card reader's datasheet for complete information.

The wire connections to the battery and the head are shown in Image 32.




Image 32: MSRv008 and Read Head Connections

About us

Our mission is to understand and assess the needs of our customers and prospective customers and provide creative, responsive, timely and cost effective products by drawing upon our extensive experience and resources.

CardReaderFactory is committed to designing, manufacturing and delivering quality products, which exceed customer and regulatory requirements.

CardReaderFactory is a trading name. Please consult www.cardreaderfactory.com for company information details.

Contact details:

sales@cardreaderfactory.com

support@cardreaderfactory.com


<http://www.cardreaderfactory.com>

Related products

MSRv010

MSRv009

MSRv007



Note: all sizes are in millimeters (mm).

Visit our website for more details.



RoHS
COMPLIANT
2002/95/EC



